

PRESIDENT'S OFFICE
REGIONAL ADMINISTRATION AND LOCAL GOVERNMENT
DARES SALAAM REGION
FORM SIX MOCK EXAMINATION
CHEMISTRY 3A

Code: 132/3A

Time: 3:00 Hours Friday, 16 February, 2024 A.M.

INSTRUCTIONS

1. This paper consists **three (3)** question.
2. Answer **all** questions.
3. Question number 1 carries **20 marks** and other two (2), **15 marks** each.
4. All answers must be written in the answer booklets provided
5. Mathematical tables and non – programmable calculators may be used.
6. Cellular phones and other unauthorized materials are not allowed in the examination room
7. Write you **Examination Number** on every page of your answer booklet (s)
Atomic masses: $H = 1, C = 12, N = 14, O = 16, Na = 23, Cl = 35.5,$
 $Mn = 55, K = 39, S = 32$
Molar gas constant $R = 8.314Jk^{-1} mol^{-1}$ or $0.821 Jmol^{-1} k^{-1}$

GEPAM science hub

WhatsApp 0748978398


This paper consists of 3 printed pages

1. You are provided with the following
 N : A solution made by diluting 12.5cm³ of a given hydrogen peroxide with 500cm³ of distilled water


P : A standard solution of 0.02M potassium permanganate
 Q : A 2M sulphuric acid.

Theory

The concentrations of commercial hydrogen peroxide are usually expressed as volume strength. Volume strength refers to the volume of oxygen in litres at STP which would be liberated when one mole of hydrogen peroxide decomposes as per equation below.



Hydrogen peroxide reacts with acidified potassium permanganate according to the following equation.



Procedures.

- Pipette 20cm³ (or 25 cm³) of solution N into a conical flask. Add to it about 20cm³ of Q.
- Titrate this mixture with solution P until permanent pink colour is observed.
- Repeat this procedure (i) to (ii) obtain three more reading. Tabulate your results as shown in the table below

The volume of the pipette uses was _____ cm³

Titration number	Pilot	1	2	3
Final reading (cm ³)				
Initial readings (cm ³)				
Titre value (cm ³)				

Summary.

_____ cm³ of solution N required _____ cm³ of solution P for complete reaction

Questions.

- Write half reaction equations and overall equation to show oxidations and reduction process.
- Explain why at the end point the solution in a conical flask was pink in colour.
- Calculate the:-
 - Concentration of hydrogen peroxide in mol/dm³
 - Concentration of hydrogen peroxide in g/dm³
 - Original concentration of hydrogen peroxide in g/dm³
 - Volume strength of commercial hydrogen peroxide.

2. You are provided with following solution

H₁ : A solution of 0.5M Na₂S₂O₃


H₂ : A solution of 0.1M HCl

Stop watch / stop clock

Thermometer (0°C – 100°C)

Theory

A white precipitate of amorphous Sulphur can be obtained by the action of dilute acid on sodium thiosulphate according to the equation



The precipitated Sulphur causes the solution to become opaque. From this phenomenon, you can assess the rate of Sulphur precipitated by measuring the time taken for the solution to become totally opaque by Sulphur.

Procedures.

- Use a blue/ black pointed pen draw a letter X on a piece of white paper and place a small beaker on top of letter X such that the letter X is visible through the solution
- Prepare water bath
- Measure 10cm³ of H₁ and 10cm³ of H₂ into separate boiling tubes.
- Put the two boiling tubes containing solution H₁ and H₂ in to water bath and warm the content to about 50°C.
- Immediately pour the hot solution H₁ and H₂ into a small beaker on top of letter X and simultaneously start the stop watch. Record the time of disappearance of letter X through your eyes.
- Repeat the whole procedure using the temperature 60°C, 70°C and 80°C. Record your result in a table form as shown below.

Temperature (°C)	K	time (sec)	1/t (sec ⁻¹)	Log 1/t (sec ⁻¹)	1/T (K ⁻¹)
50					
60					
70					
80					

Question

- Plot a graph of log 1/t against 1/T (K⁻¹)
- Determine the slope of the graph obtained in (a) above
- Determine the activation energy (E_a)
- Determine the value of pre – exponential factor (A)

3. Sample M is simple salt containing one cation and one anion. Carefully carry out qualitative analysis experiment to identify the ions present in the salt based on the following tests.

- Appearance of the sample
- Actions of heat on the solid sample
- Solubility
- Action of aqueous NaOH on a solution M
- Action of fresh prepare FeSO₄ solution on solution of M followed by conc. H₂SO₄ through the side of the test tube.
- Action of lead ethanoate and then boil
- Perform a confirmation test for the cation and anion.

Questions

- Prepare relevant table showing the qualitative analysis results.
- Write a balanced chemical equation for the reaction in experiment(b)
- The cation present in sample M was _____ and the anion was _____
- Write chemical formula of the sample M.

PRESIDENT'S OFFICE
REGIONAL ADMINISTRATION AND LOCAL GOVERNMENT
DAR ES SALAAM REGION
FORM SIX MOCK EXAMINATION-2024
CHEMISTRY 3A
MARKING SCHEME

GEPAM science hub

WhatsApp 0748978398

1. The Volume of the pipette used was 25 cm³

(0.5)

Table of Results:

Titration number	Pilot	1	2	3
Final reading (cm ³)	15.60	15.50	15.40	15.40
Initial reading (cm ³)	0.00	0.00	0.00	0.00
Titre value (cm ³)	15.60	15.50	15.40	15.40

(0.4)

$$\text{Average Volume used} = \left(\frac{V_1 + V_2 + V_3}{3} \right) \text{ cm}^3$$

T = 0.5
A.C = 0.2
D.P = 0.1

$$= \left(\frac{15.50 + 15.40 + 15.40}{3} \right) \text{ cm}^3$$

$$= 15.43 \text{ cm}^3$$

∴ The average Volume Used = 15.43 cm³

(0.1)

Summary:

25.00 cm³ of Solution N required 15.43 cm³ of Solution P for Complete reaction.


(0.1)

(a) Reduction half reaction:




(0.5)

Oxidation half reaction:



(0.5)


Overall reaction equation:



(0.1)

(b) (i) Concentration of H_2O_2 in mol/dm^3

- From the equation:



$$M_{MnO_4^-} = 0.02M$$

$$V_{MnO_4^-} = 15.43cm^3$$

$$V_{H_2O_2} = 25cm^3$$

$$n_{MnO_4^-} = 2$$

$$n_{H_2O_2} = 5$$

$$M_{H_2O_2} = ?$$

Then;

$$\frac{M_{MnO_4^-} \cdot V_{MnO_4^-}}{M_{H_2O_2} \cdot V_{H_2O_2}} = \frac{n_{MnO_4^-}}{n_{H_2O_2}}$$

(of $\frac{1}{2}$)

$$M_{H_2O_2} = \frac{M_{MnO_4^-} \cdot V_{MnO_4^-} \cdot n_{H_2O_2}}{V_{H_2O_2} \cdot n_{MnO_4^-}}$$

$$= \frac{0.02M \times 15.43cm^3 \times 5}{25cm^3 \times 2}$$

(of $\frac{1}{2}$)

$$= 0.03086M$$

$\therefore$ The Concentration of $H_2O_2 = 0.03086M$

(of 1)

(ii) Concentration of H_2O_2 in g/dm^3

From:

$$\text{Molarity} = \frac{\text{Concentration (g/dm}^3\text{)}}{\text{Molar mass}} \quad \left(\frac{0.1}{2}\right)$$

$$\begin{aligned}\text{Concentration (g/dm}^3\text{)} &= \text{Molarity} \times \text{Molar mass} \\ &= 0.03086 \text{ mol/dm}^3 \times 34 \text{ g/mol} \quad \left(\frac{0.1}{2}\right) \\ &= 1.049 \text{ g/dm}^3\end{aligned}$$

$\therefore$ The Concentration of $H_2O_2 = 1.049 \text{ g/dm}^3$ (01)

(iii) Original Concentration of H_2O_2 in g/dm^3

$$M_d = 0.03086 \text{ M}$$

$$V_d = 512 \text{ cm}^3$$

$$M_c = ?$$

$$V_c = 12.5 \text{ cm}^3$$

From Dilution law;

$$M_c V_c = M_d V_d \quad \left(\frac{0.1}{2}\right)$$

$$M_c = \frac{M_d V_d}{V_c}$$

$$= \frac{0.03086 \text{ M} \times 512 \text{ cm}^3}{12.5 \text{ cm}^3} \quad \left(\frac{0.1}{2}\right)$$

$$M_c = 1.264 \text{ M} \quad (01)$$


But;

$$\begin{aligned}\text{Concentration} &= \text{Molarity} \times \text{Molar Mass} \quad \left(\frac{01}{2}\right) \\ &= 1.264 \text{ M} \times 34 \text{ g/mol} \quad \left(\frac{01}{2}\right) \\ &= 42.98 \text{ g/mol}\end{aligned}$$

$\therefore$ The Original Concentration of $\text{H}_2\text{O}_2 = 42.98 \text{ g/mol}$ $\left(\frac{01}{2}\right)$

(iv) Volume strength of H_2O_2

From the equation of decomposition of H_2O_2 :



From the equation above;

2 moles of $\text{H}_2\text{O}_2 \equiv 1 \text{ mol of } \text{O}_2$

but 1 mol of O_2 at STP = 22.4 dm^3

and 2 mol of $\text{H}_2\text{O}_2 \equiv 2 \times 34 \text{ g} = 68 \text{ g}$ $\left(\frac{01}{2}\right)$

Then;

$68 \text{ g of } \text{H}_2\text{O}_2 \equiv 22.4 \text{ dm}^3$

$42.98 \text{ g of } \text{H}_2\text{O}_2 \equiv x \text{ dm}^3$ $\left(\frac{01}{2}\right)$

$$x = 14.16 \text{ dm}^3$$

$\therefore$ The Volume strength of $\text{H}_2\text{O}_2 = 14.16 \text{ dm}^3$ $\left(\frac{01}{2}\right)$

2. Table of Results:

Temperature		Time(s)	$\frac{1}{t} (\text{sec}^{-1})$	$\log \frac{1}{t} (\text{s}^{-1})$	$\frac{1}{T} (\text{K}^{-1})$
$^{\circ}\text{C}$	K				
50	323	43	0.0233	-1.623	3.09×10^{-3}
60	333	20	0.0500	-1.301	3.00×10^{-3}
70	343	10	0.1000	-1.000	2.92×10^{-3}
80	353	5	0.2000	-0.69	2.83×10^{-3}

@ Cell = 0.1 mark = 0.5 Marks.

(b) Slope of the graph:

$$\text{Slope} = \frac{\Delta \log \frac{1}{t} (\text{sec}^{-1})}{\Delta \frac{1}{T} (\text{K}^{-1})} \quad (0\frac{1}{2} \text{ mark})$$

$$= \frac{-1.46 - (-0.46) \text{ sec}^{-1}}{(3.10 - 2.77) \times 10^{-3} \text{ K}^{-1}} \quad (0\frac{1}{2} \text{ mark})$$

$$= -3.21 \times 10^{-3} \text{ K}(\text{sec}^{-1})$$

$\therefore$ The slope = $-3.21 \times 10^{-3} \text{ K}(\text{sec}^{-1})$ (0.1 mark)

(c) Activation energy (E_a).


Arrhenius eqn;

$$\log \frac{1}{t} = \log A - \frac{E_a}{2.303R} \times \frac{1}{T} \quad (0.1 \text{ mark})$$

$$\text{Slope} = - \frac{E_a}{2.303R}$$

(a) GRAPH OF $\log \frac{1}{t}$ AGAINST $\frac{1}{T}$

(5)



Title = 01 mark

Scale = 01 mark

labelling of axes = 01 mark

best line = 01 mark

$$\begin{aligned}
 E_a &= -\text{slope} \times 2.303 R \\
 &= -(-3.21 \times 10^{-3} \times 2.303 \times 8.314) \text{ (0.1 mark)} \\
 &= 0.0615 \text{ kJ/mol}
 \end{aligned}$$

$\therefore$ Activation energy (E_a) = 0.0615 kJmol⁻¹ (0.1 mark)

(d) Arrhenius Constant (A).

From Arrhenius equation:

$$\begin{array}{ccccccc}
 \log \frac{1}{t} & = & -\frac{E_a}{2.303R} & \times & \frac{1}{T} & + & \log A \\
 \uparrow & & \uparrow & & \uparrow & & \uparrow \\
 y & & -m & & x & & c
 \end{array}$$

From the graph, $c = -0.2$.

Then; $A = \log^{-1}(-0.2)$

$$= 0.63 \text{ sec}^{-1}$$

$\therefore$ Arrhenius Constant (A) = 0.63 sec⁻¹

(0.1 mark)

3. S/N	Experiment	Observation	Inference
(a)	Appearance of the sample	White Crystalline Salt (00½ mark)	Non-transitional metals may be present, NO_3^- , SO_4^{2-} , Cl^- , $\text{C}_2\text{O}_4^{2-}$, CrO_4^{2-} , NO_2^- , CH_3COO^- , $\text{Cr}_2\text{O}_7^{2-}$ may be present (00½ mark)
(b)	Action of heat on the solid sample	A white sublimate and a colourless gas with chocking smell which turns moist litmus paper from red to blue. (00½ mark)	NH_4^+ may be present (00½ mark)
		Colourless gas evolved which turn blue litmus paper to red and form dense white fumes with ammonia (00½ mark)	Cl^- may be present (00½ mark)
(c)	Solubility of Sample M	Sample was soluble in cold water (00½ mark)	Soluble salt may be present (00½ mark)
(d)	Action of aqueous NaOH on Solution M	No precipitate formed (00½ mark)	NH_4^+ may be present (00½ mark)
(e)	Action of fresh prepared FeSO_4 followed by Conc. H_2SO_4	No brown ring formed (00½ mark)	NO_3^- absent (00½ mark)
		A gas was formed which turns moist blue litmus paper red and form a dense white fume on adding Conc. H_2SO_4	Cl^- may be present

S/N	Experiment	Observation	Inference.
(f)	Action of Lead ethanoate and boiled.	White ppt. formed which dissolve slowly on boiling (00½ mark)	Cl ⁻ may be present. (00½ mark)
(g)	To a small solid sample, dil. NaOH was added, then warmed. A glass rod dipped in a conc. HCl passed to the mouth of the test tube.	Colourless gas which form white fumes with Conc. HCl and turn moist red litmus to blue evolved (01 mark)	NH ₄ ⁺ Confirmed (01 mark)
	To a small volume of sample solution M, dil. HNO ₃ was added followed by addition of AgNO ₃ then ammonia solution.	White precipitates Soluble in dilute ammonia solution was observed. (01 mark)	Cl ⁻ Confirmed (01 mark)

- (ii) $\text{NH}_4\text{Cl(s)} \xrightarrow{\text{Heat}} \text{NH}_3\text{(g)} + \text{HCl(g)}$ (02 marks)
- (iii) The Cation was NH_4^+ and anion was Cl^- (01 mark)
- (iv) Sample M was NH_4Cl